




HANGER SURGE RESTRAINT














Function: Designed to restrict the upward movement of activated fire sprinkler

systems. Grips ring hanger, not the nut, and allows for fine tuning

adjustments.

Material: Spring steel, Galvanized plate.

Finish: Plain, Electro-galvanized, Pre-galvanized

Install: Installs easily before or after pipe installation and without tools. Simply clip

surge restraint onto the ring hanger and run the hanger rod down to the

bottom plate surface to ensure proper restraint.

Ordering: Part number 3600310-NFE

Note: Use on 1/2" to 2" pipe, one size fits all.



^{*} UL/ULC Listed under Meide Archung part number YZJ.