



IPEX BlazeMaster® Fire Sprinkler Pipe & Fittings Submittal Sheet

IMPORTANT

Refer to Technical Data Sheet IFP2030 for warnings pertaining to regulatory and health information.

General Description

IPEX BlazeMaster Pipe and Fittings produced by IPEX USA LLC are designed exclusively for use in wet and low pressure dry pipe automatic fire sprinkler systems. The IPEX Pipe and Fittings are produced from BlazeMaster® compound that is a specially developed thermoplastic compound composed of post chlorinated polyvinyl chloride (CPVC) resin and state of the art additives. IPEX BlazeMaster Pipe and Fittings are easier to install than traditional steel pipe systems, and at the same time, provide superior heat resistance and strength as compared to traditional CPVC and PVC piping materials used in the plumbing trade. Various adapters are available to connect CPVC pipe to metallic piping. All female pipe thread adapters have brass inserts for durability. Grooved adapters connect directly to grooved end valves and metallic pipe, with flexible grooved end couplings.

The CPVC Pipe and Fittings produced with BlazeMaster compound described herein must be installed and maintained in compliance with this document and with the applicable standards of the NATIONAL FIRE PROTECTION ASSOCIATION (NFPA), in addition to the standards of any authorities having jurisdiction. Failure to do so may impair the performance of these devices.

The owner is responsible for maintaining their fire protection system and devices in proper operating condition. Contact the installing contractor or product manufacturer with any questions.



Technical Data

Approvals

UL and C-UL Listed
FM Approved
LPCB Approved
NSF Certified
MEA Approved

Refer to the latest edition Technical Manual TM-2000 for current listing/approval information.

Sizes

3/4 Inch to 3 Inch

Maximum Working Pressure

175 psi

Manufacture Source

U.S.A.

Material

Pipe:
ASTM F442, SDR 13.5

Fittings:
ASTM F438 (Sch. 40)
ASTM F439 (Sch. 80)
ASTM F1970

Color

Orange

Installation

IPEX BlazeMaster Pipe and Fittings are to be installed in accordance with Technical Manual TM-2000.

Care and Maintenance

IPEX BlazeMaster Pipe and Fittings are to be maintained and serviced in accordance with this section.

Before closing a fire protection system control valve for inspection or maintenance work on the fire protection system that it controls, permission to shut down the affected fire protection system must first be obtained from the proper authorities and all personnel who may be affected by this action must be notified.

After placing a fire protection system in service, notify the proper authorities and advise those responsible for monitoring proprietary and/or central station alarms.

The owner is responsible for the inspection, testing, and maintenance of their fire protection system and devices in compliance with this document, as well as with the applicable standards of the NATIONAL FIRE PROTECTION ASSOCIATION (e.g., NFPA 25), in addition to the standards of any authority having jurisdiction. Contact the installing contractor or product manufacturer with any questions.

Automatic sprinkler systems should be inspected, tested, and maintained by a qualified Inspection Service in accordance with local requirements and/or national codes.

Customers call IPEX USA LLC. | Toll free: (800) 463-9572 | www.ipexna.com

© 2024 by IPEX Inc. All rights reserved. No part of this book may be used or reproduced in any manner whatsoever without prior written permission.
For information contact: IPEX Management Inc. at 1383 North Service Road East, Oakville, Ontario, Canada, L6H 1A7.

NATIONAL FIRE PROTECTION ASSOCIATION and NFPA are registered trademarks of National Fire Protection Association;
BlazeMaster® is manufactured by IPEX USA LLC, and distributed in Canada by IPEX Inc.
BlazeMaster® is a registered trademark of the Lubrizol Corporation.

